

ISTRUZIONI CASSAFORTE ELETTRONICA

Programmazione del codice segreto utente

- A porta aperta, premere il **tasto rosso** posto sul retro della porta vicino alla cerniera; si accende il led giallo e viene emesso un bip corto.
- Entro 30 secondi, digitare il **codice segreto** da impostare, che può essere composto da 3 fino a 8 cifre, usando i numeri da "0" a "9".
- Premere il **tasto "E"** per confermare.

Cambio del codice segreto utente

Per cambiare il codice segreto utente, ripetere le operazioni descritte nel paragrafo precedente "Programmazione del codice segreto utente".

Apertura cassaforte

- Digitare il **codice segreto** utente.
- Premere il **tasto "E"**; si accende il led verde.
- Entro 5 secondi ruotare il **pomello** in senso orario per aprire la porta.

Se si digita un tasto errato, premere il tasto "C" per cancellare.

Nota:

- digitando qualsiasi tasto, il led giallo emette un flash ed un breve bip sonoro a conferma del corretto inserimento;
- se viene digitato un codice errato, il led giallo lampeggia con flash ripetuti ed emette bip sonori in sequenza;
- se viene inserito un codice errato per tre volte consecutive, la cassaforte si blocca per 20 secondi; un ulteriore inserimento di codice errato provoca il blocco per 5 minuti.

Chiusura cassaforte

Chiudere la **porta** e girare il **pomello** in senso antiorario per bloccare la cassaforte.

Sostituzione delle batterie

Se, quando digitate il vostro codice, si accendono contemporaneamente il led verde ed il led rosso, significa che le batterie si stanno esaurendo. **Avvertire il Ricevimento** che provvederà alla sostituzione.

Apertura di emergenza

Nel caso non fosse più possibile aprire la cassaforte, per dimenticanza del proprio codice segreto o per il completo esaurimento delle batterie, si prega di **avvertire il Ricevimento dalle ore 8:00 alle ore 22:00**. Né il personale ai piani, né il manutentore sono in possesso della chiave di sblocco.

OPERATING INSTRUCTION MANUAL FOR ELECTRONIC SAFE

To program the user code

- While the door is open, press the **red button** behind the door; the yellow light will be on with a short beep.
- Within 30 seconds, input the **user code**, which you want program, from 3 to 8 digits using any number from "0" to "9".
- Press **"E"** to confirm.

To change the user code

To change the user code, please operate in the same way as above "To program the user code".

To open the safe

- Input the **user code** you programmed.
- Press **"E"**; the green light will turn on.
- Within 5 seconds please turn the **knob** clockwise and pull out to open the safe.

If a wrong digit is input, press "C" to cancel it.

Note:

- each time you press a button, the yellow light will flash with a short beep, indicating that micro processor confirmed it;
- if you input a wrong user code, the yellow light keeps on flashing with the beep;
- if you digit three times a wrong user code the micro processor refuses to accept the input for 20 seconds; if you digit once more a wrong user code the micro processor refuses to accept the input for another 5 minutes.

To close the safe

Closing the **door** and turning the **knob** anti-clockwise will lock the safe.

To replace the batteries

When you input your personal code to open the safe and the red light is on together with the green light, it means the batteries are low. Please **contact the Reception** to replace them.

Override key

To open the safe at all times, even if the batteries are run down or when you have forgotten your code, please **contact the Reception from 8:00 a.m. until 10:00 p.m.**